



## Outdoor Waterproof Cover User Guide

1. Before you fit your new cover, please check that no damage has occurred during transit which could result in a leakage.
2. When fitting the cover, it is important to allow water to freely run off. This reduces the chance of water pooling, particularly over sewn seams. This can be done by putting something under the cover in the centre to create a tent-like effect. A simple solution is to use a small bucket or an inflatable ball.
3. When securing the cover on your product, ensure it does not chafe on any sharp edges.
4. These deluxe covers are manufactured from a waterproof and breathable 750 denier polyester fabric to help protect your HEX Living product from rain, dirt and UV rays.
5. Condensation can form, due to temperature changes and is often mistaken as a leakage. Therefore cushions should never be left out for extended periods as they may get damaged by mold or mildew growth. Ideally during winter months, cushions should be stored away in a dry environment like in a garden shed.
6. Our breathable fabric helps to release trapped condensation, however we would recommend airing off the covers periodically.
7. Although these covers are designed to help protect your product, we cannot guarantee this in severe weather conditions.
8. We recommend that you check your cover on a regular basis to ensure no damage has occurred during severe weather conditions.
9. To clean your product, wipe down with a detergent-free, warm soapy water using a non-abrasive sponge.

**Customer Service: +44 (0) 1889 272 056**