


# Alton

Large Metal Storage Apex Shed Assembly Guide

10 x 6 ft (3.0 x 1.8 m)



**IMPORTANT: PLEASE REGISTER YOUR HEX LIVING PRODUCT AFTER ASSEMBLY**

Using the unique serial number, simply register your product at [www.hexliving.co.uk](http://www.hexliving.co.uk) or use the QR code above to access the HEX Living lifetime warranty and online support.

Affix Serial Number  
HERE



PLEASE READ THIS DOCUMENT FULLY PRIOR TO STARTING ASSEMBLY PROCEDURE

The objective of this instruction is to illustrate the recommended assembly sequence for this product, any deviation from this will be the sole responsibility of whoever carries out the assembly.

IMPORTANT: IT IS ADVISABLE THAT THE PRODUCT IS ASSEMBLED AT, OR AS CLOSE AS POSSIBLE TO WHERE IT WILL BE FINALLY LOCATED

Ensure there is adequate clearance where the product is to be located:

Exterior dimensions including overhang (L x W x H)	1890 x 3000 x 2120mm
Footprint dimensions (L x W)	2900 x 1700mm
Clearance required for door to open (W x H)	Doors open outwards 1454 x 1820mm

TWO PERSON ASSEMBLY

Most procedures will not require two people but it may be easier to have assistance.



PERSONAL PROTECTION EQUIPMENT

We advise appropriate personal protective equipment is worn during assembly including eye protection and gloves.



Eye Protection



Gloves

CARING FOR YOUR HEX LIVING PRODUCT

- Your **HEX Living** product is designed to stand the test of time, which is why we're happy to offer a lifetime warranty on our products. With zero maintenance required, simply assemble your HEX Living product and enjoy putting it to great use in your garden.
- Periodically, you might want to give your product a clean, these simple care tips are not essential to the performance of your product:
  - Remove surface dirt with plain water using a jet wash or sponge, the coating on our products will ensure dirt or mud simply wipes away.
  - If your product has guttering, remove leaves and garden debris as you would on your home.

WARNINGS AND ADVISORIES

- Do not try to install the shed alone. If the shed falls, it could cause serious injuries and damages!**  
**Select a dry and calm day for your assembly, do not try to install this product in windy conditions!**
- Please read the manual carefully before assembling, (we recommend keeping the manual for future use).
- We advise a flat hard floor surface, preparing suitable area for assembly.**
- Place all parts out carefully, ideally on a soft surface to protect parts from getting damaged.
- Please check part quantities before assembling, contact customer service if any parts are missing or damaged.

PRODUCT REGISTRATION

- IMPORTANT:** Thank you for purchasing our **Hixon Shed**, ensure you have registered your HEX Living product using the unique serial number found on the cover of this document, please visit [www.hexliving.co.uk](http://www.hexliving.co.uk) to register your product and access the HEX Living lifetime warranty.

GROUND ANCHOR KIT

A Ground Anchor Kit is supplied, this is to secure the product to a solid concrete base, the shed has x4 clamp plates in each corner.

- We strongly advise That the Shed is anchored using this kit.**


The diagram illustrates the typical fixing method, once the shed is assembled, access the clamp brackets by removing the appropriate floor panel and secure as required.

GROUND ANCHOR KIT 0205-56

Part Ref: FK8  
M8 x 50mm Coach Screw  
Qty: x8



Part Ref: FK7  
Expansion Plug  
Qty: x8




# Assembly Guide


**ENSURE ALL ITEMS LISTED ARE PRESENT PRIOR TO STARTING ASSEMBLY PROCEDURE**

SCALE OF ITEMS WILL VARY TO AID VISUAL IDENTIFICATION


Part Ref: 0205-78  
Qty: x2




Part Ref: 0212-03  
Qty: x2




Part Ref: 0215-22  
Qty: x2




Part Ref: 0205-08  
Qty: x1




Part Ref: 0205-13 (1850 x 425mm)  
Qty: x3




Part Ref: 0205-12 (1850 x 625mm)  
Qty: x10



Part Ref: 0205-50  
Qty: x2




Part Ref: 0205-75  
Qty: x2




# Assembly Guide

**ENSURE ALL ITEMS LISTED ARE PRESENT PRIOR TO STARTING ASSEMBLY PROCEDURE**  
SCALE OF ITEMS WILL VARY TO AID VISUAL IDENTIFICATION


Part Ref: 0205-14 (1885mm Long)  
Qty: x4




Part Ref: 0215-02  
Qty: x2




Part Ref: 0252-01  
Qty: x1




Part Ref: 0244-06  
Qty: x4




Part Ref: 0205-16 (R/H)  
Qty: x1




Part Ref: 0244-04  
Qty: x8



Part Ref: 0205-17 (L/H)  
Qty: x1



Part Ref: 0244-05  
Qty: x2







# Assembly Guide

**ENSURE ALL ITEMS LISTED ARE PRESENT PRIOR TO STARTING ASSEMBLY PROCEDURE**  
SCALE OF ITEMS WILL VARY TO AID VISUAL IDENTIFICATION


Part Ref: 0244-03  
Qty: x2




Part Ref: 0205-81  
Qty: x1




Part Ref: 0205-18  
Qty: x2




Part Ref: 0252-05  
Qty: x2




Part Ref: 0244-16  
Qty: x4




Part Ref: 0252-08  
Qty: x1



Part Ref: 0205-37 (Left-hand)  
Qty: x1




Part Ref: 0205-97 (Right-hand)  
Qty: x1




# Assembly Guide

**ENSURE ALL ITEMS LISTED ARE PRESENT PRIOR TO STARTING ASSEMBLY PROCEDURE**  
SCALE OF ITEMS WILL VARY TO AID VISUAL IDENTIFICATION



Part Ref: 0244-15  
Qty: x2



Part Ref: 0244-11  
Qty: x2




Part Ref: 0205-85  
Qty: x2




**SHELF & RAIL KIT 0205-BLACK-SRH**

Part Ref: 0205-38-01  
Qty: x2



Part Ref: 0205-38-02  
Qty: x2



**TOOL HANGER KIT 0205-BLACK-TH**

Part Ref: 0205-39  
Qty: x2




# Assembly Guide

**ENSURE ALL ITEMS LISTED ARE PRESENT PRIOR TO STARTING ASSEMBLY PROCEDURE**  
SCALE OF ITEMS WILL VARY TO AID VISUAL IDENTIFICATION

Part Ref: 0203-03  
Qty: x4



Part Ref: 0203-41  
Qty: x1



Part Ref: 0203-15  
Qty: x4




Part Ref: 0205-57  
Qty: x4



Part Ref: 0203-28 (L/H Assembly)  
Qty: x2



Part Ref: 0205-63  
Qty: x2




Part Ref: 0203-27 (R/H Assembly)  
Qty: x2



Part Ref: 0205-66  
Qty: x2



Part Ref: 0203-32 (Assembly)  
Qty: x1



Part Ref: 0205-68  
Qty: x4




Part Ref: 0205-52  
Qty: x1




Part Ref: 0205-53  
Qty: x1




Part Ref: 0203-33 (Assembly)  
Qty: x1



Part Ref: 0203-34 (Assembly)  
Qty: x1




Part Ref: 0203-35  
Qty: x2




Part Ref: 0203-36  
Qty: x1



Part Ref: 0203-37  
Qty: x4



Part Ref: 0203-39  
Qty: x4



Part Ref: 0203-40  
Qty: x4



Part Ref: 0203-57  
Qty: x4



## FIXING KIT 0212-17

Part Ref: FK1  
M4 x 10mm Roofing Bolt  
This will be Pozi OR Slotted  
Qty: x364



Part Ref: FK2  
No.8 x 13mm Eco Fix  
Qty: x29



Part Ref: FK3  
M4 x 12mm C'Sunk Pozi Pan  
Qty: x35



Part Ref: FK4  
M4 Rubber Washer  
Qty: x79



Part Ref: FK5  
M4 Serrated Flange Nut  
Qty: x390



Part Ref: FK6  
M8 Serrated Flange Nut  
Qty: x5




## GROUND ANCHOR KIT: 0205-56

Part Ref: FK7  
Expansion Plug  
Qty: x8



Part Ref: FK8  
M8 x 50mm Coach Screw  
Qty: x8




# Understanding Your Shed Box Kits

## A STEP-BY-STEP GUIDE

AS MANY OF OUR SHEDS UTILISE COMMON PARTS, WE TOOK THE DECISION TO RESTRUCTURE THE PACKING INTO SMALLER AND LIGHTER BOXES. THE OVERALL AIM WAS TO SIMPLIFY THE PROCESS OF LOCATING THE CORRECT PARTS DURING THE SHED BUILDING PROCESS.


FOR IDENTIFICATION PURPOSES EACH BOX HAS A **UNIQUE ID CODE**, THE LIST BELOW SHOWS WHAT ORDER THESE SHOULD BE OPENED WHEN BUILDING YOUR SHED;

- F\*** - FLOOR RAILS (INC. FIXING KIT)
- P\*** - CORNER POSTS
- W\*** - WALL PANELS (TYPICALLY THREE BOXES)
- I\*** - INFILL PANELS
- T\*** - ROOF TRIM
- R\*** - ROOF PANELS
- D\*** - DOORS



## EXAMPLE ID LABEL

EACH BOX IS CLEARLY LABELLED WITH A WHITE STICKER AS PER EXAMPLE BELOW. THIS CONTAINS THE FOLLOWING USEFUL INFORMATION.





## ALSO THINK ABOUT HOW TO MAINTAIN YOUR WORKSPACE


1. DURING THE SHED BUILDING PROCESS, WE WOULD RECOMMEND KEEPING UNUSED BOXES AWAY FROM THE ASSEMBLY AREA TO REDUCE CLUTTER.
2. WHILST THE BOXES AND INTERNAL PACKAGING OFFER GREAT PROTECTION, PLEASE ENSURE THE ASSEMBLY AREA IS KEPT CLEAN AND FREE OF DEBRIS.
3. CAREFULLY REVIEW YOUR HEX LIVING ASSEMBLY GUIDE, PRIOR TO STARTING THE SHED ASSEMBLY.

**ASSEMBLY STAGE 1**

LOCATE AND SECURE A CORNER BRACE 0203-03 AT EACH LOCATION INDICATED.





SECURE EACH CORNER BRACE 0203-03 AS SHOWN ABOVE.




PLEASE NOTE: SECTION VIEW OF TYPICAL FIXING METHOD.

## ASSEMBLY STAGE 2

LOCATE AND LOOSELY ATTACH WALL PANEL 0205-13 (1850 x 425mm).



LOCATE WALL PANEL 0205-13 INTO POSITION AS SHOWN ABOVE.  
**IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.





LOOSELY ATTACH WALL PANEL ONTO FLOOR RAIL AT LOCATION INDICATED.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.




## ASSEMBLY STAGE 3

LOCATE AND LOOSELY ATTACH CORNER POST 0205-14 (1885mm).





LOCATE CORNER POST 0205-14 (1855mm) AS SHOWN ABOVE.




LOOSELY ATTACH CORNER POST AT LOCATION INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.

**ASSEMBLY STAGE 4**  
LOCATE AND LOOSELY ATTACH LONG CENTRE BRACE 0205-08.



LOCATE AND LOOSELY ATTACH LONG CENTRE BRACE 0205-08 AS SHOWN AT x2 LOCATIONS INDICATED ABOVE.





LOOSELY ATTACH AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.


# Assembly Guide

## ASSEMBLY STAGE 5

LOCATE AND LOOSELY ATTACH WALL PANEL 0205-12 (1850 x 625mm).



LOCATE AND LOOSELY ATTACH WALL PANEL AT x3 LOCATIONS INDICATED. **IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.





LOOSELY ATTACH AT LOCATIONS INDICATED ONLY.


# Assembly Guide

## ASSEMBLY STAGE 6

LOCATE AND LOOSELY ATTACH CORNER POST 0205-14 (1885mm).





6A LOCATE CORNER POST 0205-14 (1885mm) AS SHOWN ABOVE.




6B LOOSELY ATTACH CORNER POST AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT UPPER FIXING POINT AT THIS STAGE.

ASSEMBLY STAGE 7

LOCATE AND LOOSELY ATTACH WALL PANEL 0205-13 (1850 x 425mm).





7A LOCATE FIRST WALL PANEL 0205-13 (1850 x 425mm) AS SHOWN ABOVE.  
**IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.




7B LOOSELY ATTACH WALL PANEL AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE ANY FIXING POINTS OTHER THAN THOSE INDICATED.

**ASSEMBLY STAGE 8**  
LOCATE AND LOOSELY ATTACH MID CENTRE BRACE 0212-03.



LOCATE AND LOOSELY ATTACH MID CENTRE BRACE 0212-03 AS SHOWN AT x5 LOCATIONS INDICATED ABOVE.





LOOSELY ATTACH AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.




ASSEMBLY STAGE 9

LOCATE AND LOOSELY ATTACH WALL PANEL 0205-12 (1850 x 625mm).





LOCATE AND LOOSELY ATTACH WALL PANEL AT x3 LOCATIONS INDICATED. **IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.




LOOSELY ATTACH AT LOCATIONS INDICATED ONLY.

**ASSEMBLY STAGE 10**  
LOCATE AND LOOSELY ATTACH CORNER POST 0205-14 (1885mm).





10A LOCATE CORNER POST 0205-14 (1885mm) AS SHOWN ABOVE.




10B LOOSELY ATTACH CORNER POST AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT UPPER FIXING POINT AT THIS STAGE.

**ASSEMBLY STAGE 11**  
LOCATE AND LOOSELY ATTACH WALL PANEL 0205-12 (1850 x 625mm).





LOCATE FIRST WALL PANEL 0205-12 (1850 x 625mm) AS SHOWN ABOVE.  
**IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.




LOOSELY ATTACH WALL PANEL AT LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE ANY FIXING POINTS OTHER THAN THOSE INDICATED.

**ASSEMBLY STAGE 12**  
LOCATE AND LOOSELY ATTACH CENTRE BRACE 0205-85.





LOCATE AND LOOSELY ATTACH CENTRE BRACE 0205-85 AS SHOWN AT x3 LOCATIONS INDICATED ABOVE.




LOOSELY ATTACH AT x3 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.

**ASSEMBLY STAGE 13**  
LOCATE AND LOOSELY ATTACH CENTRE BRACE 0212-03.





LOCATE AND LOOSELY ATTACH LONG CENTRE BRACE 0212-03 AS SHOWN AT x2 LOCATIONS INDICATED ABOVE.




LOOSELY ATTACH AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.

ASSEMBLY STAGE 14

LOCATE AND LOOSELY ATTACH WALL PANELS 0205-12 (1850 x 625mm).



LOCATE AND LOOSELY ATTACH WALL PANEL AT x3 LOCATIONS INDICATED.  
**IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.





LOOSELY ATTACH AT x3 LOCATIONS INDICATED ONLY.




## ASSEMBLY STAGE 15

LOCATE AND LOOSELY ATTACH CENTRE BRACE 0205-85.





LOCATE AND LOOSELY ATTACH LONG CENTRE BRACE 0205-85 AS SHOWN AT LOCATION INDICATED ABOVE.




LOOSELY ATTACH AT LOCATION INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT OUTER FIXING POINTS AT THIS STAGE.

ASSEMBLY STAGE 16

LOCATE AND LOOSELY ATTACH WALL PANEL 0205-13 (1850 x 425mm).



LOCATE AND LOOSELY ATTACH WALL PANEL AT x3 LOCATIONS INDICATED. **IMPORTANT:** ENSURE PANEL IS IN THE CORRECT ORIENTATION.






LOOSELY ATTACH AT x3 LOCATIONS INDICATED ONLY.


ASSEMBLY STAGE 17  
LOCATE AND LOOSELY ATTACH CORNER POST 0205-14 (1885mm).



!  
x2 HOLES AT TOP





17A  
LOCATE CORNER POST 0205-14 (1885mm) AS SHOWN ABOVE.




17B  
LOOSELY ATTACH CORNER POST AT x2 LOCATIONS INDICATED ONLY.  
**IMPORTANT:** DO NOT SECURE AT UPPER FIXING POINT AT THIS STAGE.

**ASSEMBLY STAGE 18**  
LOCATE AND LOOSELY ATTACH LEFT-HAND DOOR POST 0205-17.





18A LOCATE LEFT-HAND DOOR POST 0205-17 AS SHOWN ABOVE.




18B SECURE DOOR POST AT x2 LOCATIONS INDICATED.  
**IMPORTANT:** DO NOT SECURE AT UPPER FIXING POINT AT THIS STAGE.

ASSEMBLY STAGE 19

LOCATE AND LOOSELY ATTACH RIGHT-HAND DOOR POST 0205-16.





LOCATE RIGHT-HAND DOOR POST 0205-16 AS SHOWN ABOVE.




SECURE DOOR POST AT x2 LOCATIONS INDICATED.  
**IMPORTANT:** DO NOT SECURE AT UPPER FIXING POINT AT THIS STAGE.

ASSEMBLY STAGE 20

LOCATE AND LOOSELY ATTACH SHORT ROOF RAIL 0205-18.



LOCATE SHORT ROOF RAIL 0205-18 AS SHOWN ABOVE.





LOOSELY ATTACH AT x15 LOCATIONS INDICATED.




ASSEMBLY STAGE 21

LOCATE AND LOOSELY ATTACH LONG ROOF RAIL 0215-02.




SLOT INTO DOOR POST

LOCATE LONG TOP RAIL 0215-02 AS SHOWN ABOVE.




LOOSELY ATTACH AT LOCATIONS INDICATED.

**ASSEMBLY STAGE 22**  
LOCATE GROUND ANCHOR BRACKETS 0205-57.



**!** THESE BRACKETS ARE SECURED USING GROUND ANCHOR KIT ONCE THE SHED WALL PANELS ARE FULLY ASSEMBLED (SEE PAGE 'I') **!**





**PLEASE NOTE: THESE BRACKETS ARE OPTIONAL, THEY CLAMP INTO PLACE WHEN FIXED TO A CONCRETE BASE FOR EXTRA STABILITY.**


LOCATE x4 GROUND ANCHOR BRACKETS 0205-57 AS SHOWN ABOVE, THESE ALLOW FOR FIXING TO A CONCRETE BASE AT A LATER STAGE IF DESIRED.

ASSEMBLY STAGE 23

LOCATE AND SECURE DOOR STRIP 0205-81.







23A  
LOCATE DOOR STRIP 0205-81 AS SHOWN.  
**IMPORTANT:** ENSURE DOOR STRIP IS PUSHED AGAINST DOOR POST RETURN.



23B  
SECURE DOOR STRIP ONTO FLOOR PANELS AT x2 LOCATIONS  
INDICATED, USE EXISTING HOLE AS A LOCATION GUIDE.





**ASSEMBLY STAGE 24**  
LOCATE AND SECURE ROOF INFILL SIDE 0252-05.



LOCATE AND SECURE ROOF SIDE INFILL 0252-05 AT x15 LOCATIONS INDICATED AS SHOWN ABOVE ON EACH SIDE.  
**IMPORTANT:** ENSURE ROOF SIDE INFILL 0252-05 IS FITTED ON THE INSIDE AND NOT ON THE OUTSIDE AS ILLUSTRATED ABOVE.

ASSEMBLY STAGE 25

LOCATE AND SECURE ROOF FRONT INFILL 0244-15.





LOCATE AND SECURE WINDOW ASSEMBLY 0244-15 AT LOCATIONS INDICATED AS SHOWN ABOVE.  
**IMPORTANT:** ENSURE WINDOW ASSEMBLY 0244-15 IS FITTED ON THE INSIDE AND NOT ON THE OUTSIDE AS ILLUSTRATED ABOVE.


# Assembly Guide

## ASSEMBLY STAGE 26

LOCATE AND EACH CORNER BRACKET 0203-15 TO ROOF INFILL AT FOUR LOCATIONS.





SECURE EACH CORNER BRACKET 0203-15 TO ROOF INFILLS AT LOCATIONS INDICATED AS SHOWN ABOVE.



SECURE EACH CORNER BRACKET 0203-15 TO ROOF INFILLS AT LOCATIONS INDICATED AS SHOWN ABOVE.



**ASSEMBLY STAGE 27**  
LOCATE AND SECURE ROOF SUPPORTS 0244-03.




27 LOCATE AND SECURE LONG ROOF SUPPORT 0244-03 AS SHOWN ABOVE.

## ASSEMBLY STAGE 28

LOCATE AND SECURE ROOF CHANNEL ASSEMBLY 0252-01.





SLOT ROOF CHANNEL ASSEMBLY 0252-01 INTO ROOF SUPPORT. FIXING POINT (x3 EACH SIDE) USING FASTENERS DETAILED ABOVE.



SECURE ROOF CHANNEL ASSEMBLY TO LONG ROOF SUPPORT 0252-07 FIXING POINT (x2 EACH SIDE) USING FASTENERS DETAILED ABOVE.





**ASSEMBLY STAGE 29**  
LOCATE AND SECURE ROOF PANEL 0244-04.




29  
SECURE ROOF PANELS AT x4 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

ASSEMBLY STAGE 30

LOCATE AND SECURE ROOF PANEL SIDE 0244-06.





ALIGN AND OVERLAP ROOF PANEL 0244-06 WITH ROOF PANEL SIDE AS SHOWN.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP AS SHOWN.




SECURE ROOF PANELS AT x 3 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

ASSEMBLY STAGE 31

LOCATE AND SECURE ROOF PANELS 0244-04 & ROOF PANEL SMALL 0244-05.





ALIGN AND OVERLAP ROOF PANEL WITH PREVIOUS ROOF PANEL.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP AS SHOWN.




SECURE ROOF PANELS AT LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

ASSEMBLY STAGE 32

LOCATE AND SECURE ROOF PANEL SIDE 0244-06.





ALIGN AND OVERLAP ROOF PANEL 0244-06 WITH ROOF PANEL SIDE AS SHOWN.



SECURE ROOF PANELS AT x 3 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.

ASSEMBLY STAGE 33



LOCATE AND SECURE ROOF PANEL 0244-04.




SECURE ROOF PANELS AT x4 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

## ASSEMBLY STAGE 34

LOCATE AND SECURE ROOF PANEL SIDE 0244-06.





ALIGN AND OVERLAP ROOF PANEL 0244-06 WITH ROOF PANEL SIDE AS SHOWN.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP AS SHOWN.




SECURE ROOF PANELS AT x 3 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

ASSEMBLY STAGE 35

LOCATE AND SECURE ROOF PANELS 0244-04 & ROOF PANEL SMALL 0244-05.





ALIGN AND OVERLAP ROOF PANEL WITH PREVIOUS ROOF PANEL.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP AS SHOWN.




SECURE ROOF PANELS AT LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.

## ASSEMBLY STAGE 36

LOCATE AND SECURE ROOF PANEL SIDE 0244-06.



ALIGN AND OVERLAP ROOF PANEL 0244-06 WITH ROOF PANEL SIDE AS SHOWN.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP AS SHOWN.




SECURE ROOF PANELS AT x 3 LOCATIONS INDICATED USING TYPICAL FIXING METHOD.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.




## ASSEMBLY STAGE 37


LOCATE AND SECURE ROOF RIDGE BRACKET 0244-16 TO ROOF RIDGE 0252-08.  
LOCATE AND SECURE ROOF RIDGE 0252-08 TO ROOF CHANNEL ASSEMBLY 0252-01



**NOTE:** MAKE SURE 0252-08  
EDGE IS FLUSH WITH OUTER  
SHED ROOF EDGE.  
THIS WILL HELP WITH HOLE  
ALIGNMENT, WHEN SECURING  
TO 0252-01 ROOF CHANNEL  
ASSEMBLY (FIG.35B).





37A  
SECURE ROOF RIDGE BRACKETS TO ROOF RIDGE AT x 4 LOCATIONS INDICATED.  
**IMPORTANT:** ENSURE RUBBER WASHER FK4 IS LOCATED AS SHOWN.




37B  
**NOTE:** FROM INSIDE OF SHED SECURE ROOF RIDGE 0252-08 AT x4 LOCATIONS  
INDICATED USING TYPICAL FIXING METHOD.

ASSEMBLY STAGE 38

LOCATE AND SECURE ROOF RIDGE CAPS 0244-11 TO ROOF RIDGE 0252-08.





38A SLIDE RIDGE CAP 0244-11 INTO POSITION AT FRONT & REAR OF THE SHED ROOF.



38B SECURE RIDGE CAP AT x4 LOCATIONS INDICATED USING TYPICAL FIXING METHOD. PLEASE NOTE: THE FIXING USED IS A SELF DRILLING COMPONENT.



ASSEMBLY STAGE 39

LOCATE AND SECURE ROOF GUTTER ASSEMBLY 0205-75



SLIDE AND SECURE ROOF GUTTER 0205-75 INTO POSITION AS SHOWN ABOVE.  
**IMPORTANT:** ENSURE PANELS ALWAYS OVERLAP GUTTER AS SHOWN.



**ASSEMBLY STAGE 40**  
LOCATE AND SECURE ROOF CAPS 0205-50.




SLIDE AND SECURE ROOF CAP 0205-50 INTO POSITION AS SHOWN ABOVE.  
**PLEASE NOTE:** THE FIXING USED IS A SELF DRILLING COMPONENT.

## ASSEMBLY STAGE 41

DETERMINE WHICH SIDE DRAIN HOLE 0205-53 WILL BE LOCATED.





LOCATE AN OPEN GROMMET INTO THE ROOF GUTTER ABOVE WHERE THE DRAIN HOLE WILL BE LOCATED.




LOCATE CLOSED GROMMET INTO THE ROOF GUTTER ON THE OPPOSITE SIDE TO THE LOCATED DRAIN HOLE AS SHOWN ABOVE.

ASSEMBLY STAGE 42

LOCATE AND SECURE RIGHT-HAND DOOR ASSEMBLY 0205-97 FURNITURE.




42A LOCATE EURO MORTICE LOCK 0203-32 RIGHT-HAND DOOR APERTURE AS SHOWN.




42B SECURE EURO MORTICE LOCK 0203-32 AT x2 LOCATIONS INDICATED ABOVE. SEE FOLLOWING DATA SHEET FOR COMPLETION OF MORTICE LOCK INSTALLATION.

## ASSEMBLY STAGE 42 CONTINUED


LOCATE AND SECURE RIGHT-HAND DOOR ASSEMBLY 0205-97 FURNITURE.




LOCATE AND SECURE EURO ESCUTCHEON 0203-34 AS SHOWN.  
**PLEASE NOTE:** FIXING IS PART OF THE ESCUTCHEON ASSEMBLY.




LOCATE EURO ESCUTCHEON COVER 0203-34 ONTO EURO CYLINDER AS SHOWN.  
**PLEASE NOTE:** THESE ARE PUSHED ON AND WILL CLICK INTO PLACE.




LOCATE EURO CYLINDER 0203-36 INTO DOOR APERTURE.  
**IMPORTANT:** ENSURE COVER IS FITTED AS SHOWN.



SECURE EURO CYLINDER 0203-36 AS SHOWN ABOVE.  
**PLEASE NOTE:** FIXING IS PART OF THE EURO MORTICE LOCK ASSEMBLY.





LOCATE AND SECURE DOOR HANDLE ASSEMBLY 0203-33 AS SHOWN.  
**PLEASE NOTE:** FIXING IS PART OF THE HANDLE ASSEMBLY.




LOCATE COVER ONTO DOOR HANDLE AS SHOWN.  
**PLEASE NOTE:** THESE ARE PUSHED ON AND WILL CLICK INTO PLACE.

ASSEMBLY STAGE 43

LOCATE AND SECURE DOOR BOLTS 0203-35, CATCH PLATE 0203-32 AND CATCH PLATE COVER 0203-41 AT EACH LOCATIONS INDICATED.



LOCATE AND SECURE EURO MORTICE LOCK 0203-32 AND CATCH PLATE COVER 0203-41 AS SHOWN ABOVE.




SECURED CATCH PLATE 0203-32 AS SEEN FROM FRONT.




## ASSEMBLY STAGE 43 CONTINUED


LOCATE AND SECURE DOOR BOLTS 0203-35 AT BOTH LOCATIONS INDICATED.




SECURE THE FLUSH BOLT BODY 0203-35, USING PACKERS 0203-40 AS SHOWN ABOVE, ENSURE THE THREADED BOSS IS FACING THE HOLE IN THE DOOR.




ENSURE THE LOCKING LEVER IS IN THE UNLOCKED POSITION, AS SHOWN ABOVE.



THREAD THE LOCKING NUT ONTO THE DOOR BOLT AND INSERT THROUGH THE HOLE IN THE DOOR AND SCREW INTO THE BOLT BODY 0203-35.





ADJUST THE DOOR BOLT UNTIL IT SITS FLUSH WITH THE EDGE OF THE DOOR. SECURE INTO POSITION WITH THE LOCKING NUT.




# Assembly Guide

## ASSEMBLY STAGE 44

LOCATE AND SECURE A DOOR GROMMET 0203-57 AT EACH LOCATION INDICATED.





LOCATE DOOR GROMMET 0203-57 AT x2 LOCATIONS INDICATED. PLEASE NOTE: 0203-35 FLUSH BOLTS ARE ALL IN THE UNLOCKED POSITIONS.




LOCATE DOOR GROMMET 0203-57 AT x2 LOCATIONS AS SHOWN. PLEASE NOTE: THESE ARE PUSHED ON AND WILL CLICK INTO PLACE.

ASSEMBLY STAGE 45

LOCATE AND SECURE DOOR HINGES ONTO DOOR ASSEMBLIES.





45A LOCATE DOOR HINGE PLATE 0203-37 WITHIN DOOR AS SHOWN.




45B SECURE DOOR HINGE PLATE AND HINGE 0203-27 AND 0203-28 AS SHOWN.  
IMPORTANT: ENSURE CORRECT DOOR HINGE IS SECURED TO CORRECT DOOR.

## ASSEMBLY STAGE 46

LOCATE AND SECURE DOOR HINGES ONTO LEFT-HAND & RIGHT-HAND DOOR POST.





46A  
LOCATE DOOR POST PLATE 0203-39 WITHIN DOOR FRAME AS SHOWN.  
**IMPORTANT:** ENSURE CORRECT DOOR HINGE IS SECURED TO CORRECT DOOR.




46B  
SECURE DOOR POST PLATES AND HINGES AS SHOWN.  
**PLEASE NOTE:** REPEAT EACH PROCEDURE FOR UPPER LOCATION.

ASSEMBLY STAGE 47


LOCATE AND SECURE GAS STRUT BRACKETS 0205-66.



SECURE A GAS STRUT BALL JOINT 0205-68 ONTO EACH GAS STRUT BRACKET 0205-66.





DETERMINE DOOR OPENING ANGLE:  
A: 90° OPENING OR B: 120° OPENING




ALIGN EACH GAS STRUT BRACKET WITH RELEVANT FIXING HOLES, SECURE USING TYPICAL FIXING METHOD ABOVE.

**ASSEMBLY STAGE 48**  
LOCATE DOOR ASSEMBLIES ONTO HINGES.





SLIDE EACH DOOR ASSEMBLY ONTO EACH OF THEIR RESPECTIVE HINGES.




ASSEMBLED DOOR HINGE.

## ASSEMBLY STAGE 49

LOCATE AND SECURE GAS STRUT 0205-63.




SECURE A GAS STRUT BALL JOINT 0205-68 ONTO EACH GAS STRUT BRACKET THAT IS PRE-RIVETED ONTO EACH DOOR ASSEMBLY.




FIX EACH GAS STRUT 0205-63 ONTO RELEVANT GAS STRUT BALL JOINTS. **PLEASE NOTE:** PUSHES DOWN ON DOOR AND UPWARDS ON DOOR FRAME.

ASSEMBLY STAGE 50


LOCATE AND SECURE SHELF ASSEMBLY 0205-BLACK-SRH KIT.



THE SHELF ASSEMBLY CAN BE LOCATED AS DESIRED, PLEASE DETERMINE THE MOST SUITABLE LOCATION AND ASSEMBLE AS SHOWN IN FIG.50A & 50B.




SLIDE SHELF POST UP INTO ROOF FRAME, ONCE THERE IS ENOUGH CLEARANCE AT THE BOTTOM LOCATE SHELF POST OVER FLOOR FRAME AND LOWER.



LOCATE EACH SHELF 0205-38-02 ONTO SHELF POST AS DESIRED. **PLEASE NOTE:** THE SHELF SIMPLY HOOKS ONTO THE POST.

ASSEMBLY STAGE 51

LOCATE TOOL HANGERS 0205-BLACK-TH WITHIN SHED AS DESIRED LOCATION.



HOOK EACH TOOL HANGER ONTO ROOF FRAME AT DESIRED LOCATION.



IMPORTANT

ADJUST ALL COMPONENTS FOR BEST POSSIBLE FIT AND TIGHTEN ALL FASTENERS.

ONCE ALL FASTENERS HAVE BEEN CHECKED AND ARE SECURE THE ASSEMBLY IS COMPLETE

WE RECOMMEND YOU ANCHOR YOUR SHED TO A SOLID CONCRETE BASE, GUIDANCE CAN BE FOUND ON PAGE 'I'









## Caring for your HEX Living product

Your **HEX Living product** is designed to stand the test of time, which is why we're happy to offer a **lifetime warranty** on our products. With zero maintenance required, simply assemble your HEX Living product, and enjoy putting it to great use in your garden.

Periodically, you might want to give your product a clean, these simple care tips are not essential to the performance of your product:

- Remove surface dirt with plain water using a jet wash or sponge, the coating on our products will ensure dirt or mud simply wipes away.
- If you've purchased a HEX Living metal storage solution, periodically clear the roof of fallen leaves.
- If your product has guttering, remove leaves and garden debris as you would on your home.

## Ensure you have registered your HEX Living product

Using the unique serial number found on the cover of this document, please visit **[www.hexliving.co.uk](http://www.hexliving.co.uk)** to register your product and access the HEX Living lifetime warranty and video instructions.

**Customer Service: +44 (0) 1889 272 056**

